

WK Data Logging Operations Manual



File version : 1.0

Software name : WK Data Logging

All Rights Reserved : Asia Pacific Instrument & Measurement Co., Ltd

Table of Contents

Table of Contents	ii
Figure Table of Contents	iv
Table directory	v
DISCLAIMER.....	2
CHAPTER 1.....	4
SOFTWARE INTRODUCTION	4
1.1 System Ports	4
1.2 Login Screen	4
1.3 USB Key	7
1.4 System Settings	8
1.4.1 Instrument Settings.....	9
1.4.2 Language Setting.....	9
CHAPTER 2.....	10
DASHBOARD MODE.....	10
2.1 Interface	10
2.2 Setting The Measurement Conditions.....	12
2.3 Measurement.....	13
2.4 Save The Measurement Results	13
2.5 Save The Setting Condition.....	14
2.6 Load Settings Programming.....	14
2.7 Meter Viewing.....	14
2.8 Scan The QR Code	15
2.8.1 Measurement Conditions	15
2.8.2 Material Information.....	15
2.9 Meter Mode Setting	17
2.9.1 Bias Source Setting.....	17
2.9.2 Offset Value Compensation.....	18
2.9.3 Material Properties	19
2.9.4 Material Information Setting.....	20
2.9.5 Other settings.....	20
CHAPTER 3.....	22
ANALYSIS MODE	22
3.1 Interface	22

3.2	Function Introduction.....	24
3.3	Setting The Measurement Conditions.....	25
3.4	Measurement.....	26
3.5	View Measurement Data.....	26
3.6	Save The Measurement Results	27
3.6.1	Save The Picture.....	27
3.6.2	Store data.....	27
3.7	Save The Setting Condition.....	28
3.8	Load Setting Conditions.....	28
3.9	Resonant Mode	29
3.10	Analysis Mode Setting	29
3.10.1	Bias Source Setting.....	30
3.10.2	Material Settings	31
3.10.3	Device settings	32

Figure Table of Contents

Figure 1. Connection method	4
Figure 2. Login screen	4
Figure 3. A successful connection to the instrument	6
Figure 4. USB key does not boot.....	7
Figure 5. USB Key Boot.....	8
Figure 6. System settings.....	8
Figure 7. Language settings.....	9
Figure 8. Dashboard Mode Interface	10
Figure 9. "Edit" interface of analysis mode.....	22
Figure 10. "Chart" interface of analysis mode.....	23
Figure 11. Analysis Mode System Setting.....	29
Figure 12. NI USB-TC01	32

Table Directory

Table 1. Login Screen Feature Introduction.....	5
Table 2. Dashboard Mode Feature	11
Table 3. Analysis Mode Features	25
Table 4. Thermocouple types.	32

DISCLAIMER

This software only provides the convenience of remote measurement, users and their managers should pay attention to the condition of instruments, fixtures and measured objects to avoid damage and disasters.

The author of the software and the company shall not be liable for any damage, disaster, legal liability or any other liability caused by the software, and please do not use the software if it is unacceptable.

The use of pirated software or without the company's sale and authorization, the software author and the company do not provide any technical services.

※In order to avoid any risks, please note the following:

1. Before using this software, please carefully read the instrument and software installation manual, especially the safety principal section.
2. If pirated software is used and has not been sold and licensed by the Company, the software author and the Company do not provide technical services.
3. When using this software, the software author and the company are not responsible for any damage directly or indirectly caused by the instrument caused by improper disconnection from the operation interface of this software.
4. The GPIB connection of this software adopts NI USB-488.2 GPIB card connection instrument, if the use of other brand products causes the connection to be unstable or unable to connect normally, all instruments directly or indirectly caused any damage, the software author and the company do not take any responsibility and provide any technical support.

5. No reverse engineering, reverse assembly, decompilation and other modifications to this software, any other software derived from this software that is not authorized by APAC Co., Ltd. to develop and officially release is illegal, downloading, installing, using such software will lead to unpredictable risks, all legal liabilities and disputes arising therefrom have nothing to do with the software author and the company, the software author and the company do not provide customer service services for unofficial versions of the software.

CHAPTER 1

SOFTWARE INTRODUCTION

1.1 System Ports

This software supports GPIB, USB, LAN ports, choose one to operate. An additional Ext. connection method is available to integrate external instruments.




Figure 1. Connection method

Figure 1 shows that the software provides three connection methods, choose the connection method to connect with the Wayne Kerr instrument.

1.2 Login Screen




Figure1. Login screen

Figure1 shows the software login screen, and the software version number is shown in the upper left corner.

NO.	ICON	DESCRIPTION
1		Master system settings
2		Disconnect from the instrument
3		Dashboard mode
4		Analysis mode
5		Customized projects
6		Measurement data analysis tools
7		Diagnostic window
8		Three types of ports
9		External Connection Settings
10		Specifically designed for WK4300; non-WK4300 instruments will connect the method with the software

Table1. Login screen feature introduction

According to the user's existing connection method, you can select:

GPIB

An address number is required.

LAN

Enter IP, WK4X series, default IP address is 192.168.1.245.

USB

You do not need to enter an address number.

After selecting the connection method, click Here:

連接



Figure2. A successful connection to the instrument

Figure2 shows the screen of successfully connecting to the instrument and displaying the ID of the instrument to enter the mode (Mode). This document lists the USB connection method to connect with WAYNE KERR 41100.

儀表

Enter gauge mode, refer to 0.

分析

Enter the analysis mode, refer to 0.

Cell

Custom Engineering:

1. WK5400 series, support multiple current modes.
2. WK3260 series, support transformer mode.

切換

To disconnect or reconnect, tap.

1.3 USB Key

※ You must insert a USB key before starting this software to activate the data saving function.




Figure3. USB key does not boot

Figure3 4, the word "Demo Version" appears to indicate that the USB key is not detected.




Figure4. USB Key Boot

Figure4Demo Version" does not appear, indicating that the USB key has been started.

1.4 System Settings




Figure5System settings

Figure5 6, the system settings include: meter settings and language.

1.4.1 Instrument Settings

1. External triggering: This system integrates the ADU200 for external triggering and does not require driver installation.



2. Pass/Defect LED: Additional 2021DLB purchase, no driver installation required.



Qualified light number



Bad light number

1.4.2 Language Setting




Figure6. Language settings

Figure6As Figure 7 show, three languages are currently supported.

CHAPTER 2

DASHBOARD MODE

Function:

1. Single measurement.
2. Repeat measurements.
3. Save measurement data (USB key required).
4. Scan 2D barcode, new incremental measurement conditions, material information

Quick Setup:

Setting The Measurement Conditions first (Chapter 2.22.2 and then measure MeasuSection 2.32.3

2.1 Interface




Figure7. Dashboard Mode Interface




No.	Icon	Description
1	 量測	Single-step measurement
2	 重複量測	Repeat measurements
3	 載入設定	Load the programming settings
4	 設定量測條件	Installation Edition Installation
5	 儀表觀看	Instrument viewing
6	 批次結束	End of batch measurement
	 儲存檔案	Export Survey Results
7	 設定	Measure mode setting
8	 校準	Zero calibration

Table2. Dashboard Mode feature

Table2 shows the functions of the meter mode, and the details are as follows.

2.2 Setting The Measurement Conditions



, set the test conditions of Test1/Test2, Term1, Term2, Frequency, Level, etc. and you can modify the content.




Added test conditions,



which lists the measurement

conditions. To modify the measurement conditions, first click the item you want to change,



change the item, and then click Modify



Change.



Set upper and lower limits to determine whether the measurement is good or bad. When this function is set, it will be linked if there is a pass/bad indicator light for connection. See Section 1.4.1 Subsection II.

- After setting the measurement conditions, you can measure it, refer to Section 2.3
- Save the test conditions, refer to Section 2.5
- Load test conditions, refer to Section 2.6

2.3 Measurement



take measurements.

編號	前後結果	步驟	備註(名稱/延遲)	量測條件	源波	下限	量測數值	上限	狀態
1	PASS	S1	OFF	10kHz, TV	Z ₁	-	5.41735kΩ	-	PASS
	PASS	S1	OFF	10kHz, TV	θ ₁	-	-129.5249°	-	PASS
2	PASS	S1	OFF	10kHz, TV	Z ₂	-	22.5578kΩ	-	PASS
	PASS	S1	OFF	10kHz, TV	θ ₂	-	8.535°	-	PASS
3	PASS	S1	OFF	10kHz, TV	Z ₃	-	1.80508kΩ	-	PASS
	PASS	S1	OFF	10kHz, TV	θ ₃	-	-110.3021°	-	PASS
4	PASS	S1	OFF	10kHz, TV	Z ₄	-	1.59565kΩ	-	PASS
	PASS	S1	OFF	10kHz, TV	θ ₄	-	-6.1914°	-	PASS
5	PASS	S1	OFF	10kHz, TV	Z ₅	-	11.6320kΩ	-	PASS
	PASS	S1	OFF	10kHz, TV	θ ₅	-	112.7598°	-	PASS


, which is the measurement result.

- If you need to save the test results, refer to Section 2.4
- To change the format of the measured values, refer to Section 2.9 Subsection 5.

2.4 Save The Measurement Results




End the measurement and output (save) the measurement results.




Select the save path, enter the

file name, and archive. The output file format is CSV.

2.5 Save The Setting Condition



Save the setting conditions,




select the save path, enter the file name, archive. The output file format is wkda.

2.6 Load Settings Programming



Loading settings programmatically, select the file



with the extension wkda, and load.

2.7 Meter Viewing



This function observes the change in the measured object (DUT)

measurement relative to the real-time measurement on the meter.

2.8 Scan The QR Code

The software supports scanning the QR code and entering the measurement conditions or material information. For barcode setting rules, please refer to the manual.

2.8.1 Measurement Conditions

✘ You need to set the interface in this condition to scan the input measurement conditions.



When the barcode is set incorrectly or the conditions are incorrect,




a prompt window is displayed.


2.8.2 Material Information

✘ You need to be in the instrument mode interface to scan and input material information.

If there is material information, it will be recorded in the measurement results when it is saved.



After scanning the QR code, the display of data will change from "Programming Process" to "Material Information".



Manual material information is provided as described in Section 2.9.4

2.9 Meter Mode Setting



Settings: bias source, deviation compensation, material properties, material information and other settings. The above setting function will have different settings according to different instruments, and the details are as follows:



2.9.1 Bias Source Setting

Supports WK6500 series, WK3260 series and WK5400 series. Additional purchase of biased sources is required.



The initial setting of WK Bias is turned off to prevent burst current when the function is turned on.


Off: Turn off DC Bias.

Internal: Use internal bias.

External: To use external bias current, it needs to be connected to the WK instrument to enable the function of the bias source. Such as WK6565, WK3265.

2.9.2 Offset Value Compensation

Only support WK3260 + WK3265 (need to start), when the measured value has an error value, according to the input value to add or subtract and provide six sets of setting columns, only one group can be used at a time.



Add or subtract according to the value entered by the user.

Example 1Q is set to -0.1Q, the equivalent value is 10.1Q, and the measurement result will be displayed as 10Q.

2.9.3 Material Properties

Only WK6500 is supported, testing the dielectric constant and permeability of the material.

啟用

介電常數測試

<input checked="" type="checkbox"/> 接觸	<input type="checkbox"/> 無接觸
電極直徑 'D' <input type="text" value="38.0000mm"/>	電極間距 'Tg' <input type="text" value="2.10000mm"/>
材料厚度 'Tm' <input type="text" value="1.00000mm"/>	材料厚度 'Tm' <input type="text" value="2.00000mm"/>
量測 'Cg' 參考值	
<input type="button" value="歸零"/> No Data	

磁導率測試

線圈匝數 'N' <input type="text" value="5N"/>	
平均線徑長度 'l' <input type="text" value="60.0000mm"/>	
磁環截面面積 'A' <input type="text" value="50.0000mm2"/>	
量測 'Lw/Rw' 參考值	
<input type="button" value="歸零"/> No Data	

2.9.4 Material Information Setting

Manually fill in the information, and the measurement results will be recorded when they are saved.

零件名稱

零件編號

零件批次號

零件流水號

操作人員

After entering data, all field information is

synchronized with it.

零件名稱	零件編號	零件批次號	零件流水號
IDN100uF	20220929	PR-2022-001	SER-1001

2.9.5 Other settings

1. The sequence number or name of the measurement result.

自定序列號

起始編號:

內容:

Example: Content is T; The starting number is 1, and the measurement result is numbered T1.

編號	最後結果	步驟	偏置時間 (充電, 延遲)
T1	PASS	S1	OFF
	PASS	S1	OFF

2. Display a prompt window when the measurement result fail.

提示視窗

提示! 當不良訊號出現時。

Tick to launch this feature.

3. Automatic measurement

自動量測

自動偵測 DUT...

延遲： 微秒

門檻值：

Tick to launch this feature; If the measured value meets the threshold value, it is measured.

4. The format in which the data is saved.

儲存資料格式

科學符號表示

儀器符號表示

Scientific Symbols: 10E3; Instrument symbol: 1000

CHAPTER 3

ANALYSIS MODE

Support :

1. Multiple sets of scan conditions.
2. The way to draw a picture is to present the measured values.
3. Frequency, voltage, current, time, and temperature sweep point (Sweep).
4. Compare differences under the same measurement conditions.

Quick Setup :

Set the measurement conditions first (Chapter 3.3) **Setting The Measurement**

Conditions3.3 3.4).

3.1 Interface




Figure 9. "Edit" Interface of Analysis Mode








Figure8"Chart" interface of analysis mode

Figure 10 show the analysis mode interface Figure8K Data Logging, the information in the upper left corner is the version number of the analysis mode, and the

information in the upper right corner is the instrument model and the interface type connected to the instrument.

3.2 Function Introduction

No.	Icon	Description
1	 量測	Set measurement conditions and perform measurement
2	 新增	New delta testing conditions
3	 諧振模式	Look for the resonant frequency
4	 圖表  編輯	Toggle chart Edit"
5	 設定	Supports setting of WK6565 as well as external power supply
6	 校準	Zero calibration
7	 儲存設置	Save the scan condition settings
8	 載入設置	Load scan condition settings
9		Modify the measurement conditions
9		Delete a measurement condition
10	 原始圖	After scaling, it reverts back to the original curve
11	 縮放調整	After the adjustment is scaled, the curve no longer appears in range
12	 ON  OFF	Display Hide curves
13	 載入曲線	Load stored data and present it as a curve
14	 數據表	View the measured values
15	 儲存圖片	Save the graph

16		Alignment curve
		Curve reduction/enlargement
17		Search for the peak value of the curve
		The scale shows lg(x) / Linear
18		Clear all measurement results

Table3. Analysis Mode Features

Table3 shows the functions of the meter mode, as follows.

3.3 Setting The Measurement Conditions



Add a new set of measurement conditions, which can be modified or

deleted




This is a set of measurement conditions,

including measurement settings and scan settings.

3.4 Measurement



After measurement, the points are connected with lines to form,



Default ✕

型號: 41100

測項 1: Z █

測項 2: A █

等效電路: 串聯

電平: 1.0 V

Freq.: -

偏流: -

Frequency
10.00kHz ~ 1.00MHz

click the left field to

view the curve of this pen, the background is yellow to represent the data that has been selected so far.

3.5 View Measurement Data



To view the data of each measurement, click the field on the left to view

編號	Frequency (Hz)	Z (Ω)	A (°)
1	10.0000k	24.5450k	46.6338
2	120.000k	49.9390k	-49.7305
3	230.000k	23.0823k	113.869
4	340.000k	153.281k	-17.2146
5	450.000k	86.9360k	116.346
6	560.000k	68.6628k	176.566
7	670.000k	139.441k	-73.4557
8	780.000k	183.222k	30.4208
9	890.000k	124.626k	162.395
10	1.00000M	207.399k	-77.6391

the measurement data of this transaction.


To save data, refer to Section 3.6.2

3.6 Save The Measurement Results

3.6.1 Save The Picture



Save the graph,




select the save path, enter the file name, archive; The output file format is png.

3.6.2 Store data




To save data, you need to create a folder first,




select the created folder, and archive; The output file

format is CSV.

3.7 Save The Setting Condition



Save the setting conditions,




select the save path, enter the file name, archive; The output file format is wk.

3.8 Load Setting Conditions



Set the conditions for loading, select the file



with the extension wk, and load.

3.9 Resonant Mode



, only support WK6500 series and WK6400 series to select resonance type, given the sweep frequency range; After measurement, the resonant



frequency and graph (displayed in Log) will be displayed.

3.10 Analysis Mode Setting



Settings: Partial source, material and device. The above setting function will have different settings according to different instruments, and the details are as follows:




Figure 11. Analysis Mode System Settings

3.10.1 Bias Source Setting

1. WK bias source

Only supports WK 6500 series, WK3260 series and WK 5400 series. An additional bias current source is required.



The "WK bias source" is initially set to off to prevent burst current when the function is turned on.

Off: Turn off DC Bias.

Stand-alone (Internal): Uses internal bias.

External: To use an external bias current, it needs to be connected to the WK instrument to enable the function of the bias source. Such as WK6565, WK3265.

2. Third-party bias source

Only the EA system and ITECH systems are integrated and an additional bias sources are required. If the WK bias source is supported, the third-party bias source cannot be turned on.



OVP: Over set voltage protection.

OCP: Over set current protection.

OPP: Over set wattage protection.

When measuring:

Condition 1. The set voltage value exceeds the OVP

Condition 2. The set current value exceeds the OCP

Condition 3. The set wattage value exceeds the OPP

When either condition is met, the measurement stops.

3.10.2 Material Settings

Only WK6500 is supported, testing the dielectric constant and permeability of the material. Tick off with this feature.



3.10.3 Device settings

It is necessary to measure the temperature of the measured object as the current changes, and an additional NI USB-TC01 device needs to be purchased.



Figure9. NI USB-TC01

Thermocouple type	Wire(+)	Pipe(-)
J	Iron	Nickel-copper alloy
K	Nichrome	Nichrome
N	Nichrome silicon alloy	Nickel-silicon-magnesium alloy
R	White gold 13% rhodium	platinum
S	White gold 10% rhodium	platinum
T	Copper	Nickel-copper alloy
B	White gold 30% rhodium	White gold 6% rhodium
E	Nichrome	Nickel-copper alloy

Table4. Thermocouple types.